

The **PhoneSkype SK-04** is the next-generation USB phone designed specifically for Skype with the latest technology. Simply plug it into the USB port of your PC or laptop, and you can make/answer Skype calls just as you would be on a regular telephone. It is the perfect phone for both office and home use.

Key Features

- Seamless integration with Skype without need of any special drivers or plug-in software
- Rings loudly on an incoming call
- Fully functional keypad enables you to make/receive calls even easier
- Hook switch allows for intuitive answering/ending Skype calls
- Acoustically isolated speaker and microphone to eliminate echo
- Full-duplex communication with crystal clear speech
- USB Interface PnP. No external power/sound card required
- Built-in headset jack
- Hands-free microphone and speaker
- Also compatible with other PC-based softphone applications, such as **MSN, Yahoo Message, Xten, Dialpad, MediaRing, Net2phone** and etc.
- Supports Windows and Linux

Product Specifications

<i>Dimension</i>	205 x 155 x 80mm
<i>Weight</i>	600g
<i>Operating Temperature</i>	0~50 degree
<i>Operating Humidity</i>	5% to 95% RH
<i>Connect Type</i>	One USB jack One 3.5mm microphone jack One 3.5mm speaker jack
<i>Voltage</i>	4V-5.25V DC(USB support)
<i>Codec</i>	G.711 A-law
<i>Led</i>	Power Indicate
<i>Approval</i>	CE,FCC

Standards Support

The **PhoneSkype SK-04** is a standard device in Windows and Linux so it needn't any additional driver when installed. It conforms to the following standards:

- USB version 1.1
- USB Audio Device Release 1.0

- USB HID Device Version 1.1
- USB Keyboard

Function Keys Introduction



- | | | | |
|------------|-----------|--------------------|------------|
| 1. Speaker | 5. Answer | 9. Hang up | 13. Up |
| 2. Handset | 6. Mute | 10. Search | 14. Down |
| 3. Skype | 7. Browse | 11. Dialing Keypad | 15. Delete |
| 4. Ignore | 8. Esc | 12. Tab | 16. OK |

Button	Description
<i>Skype</i>	Focus Skype. Press this button to focus Skype if it is inactive.
<i>Browse</i>	Equal to the combination keys of Ctrl+Tab . You can use it to change the current window in Skype.
<i>OK</i>	Equal to the key Enter .
<i>Delete</i>	Equal to the key Backspace
<i>Up</i>	Equal to the key Up
<i>Down</i>	Equal to the key Down
<i>Tab</i>	Equal to the key Tab . You can use it to switch the cursor between Contacts List and Number Input Text in Skype
<i>Answer</i>	Answer call
<i>Hang up</i>	Reject/Hang-up call
<i>Ignore</i>	Ignore call
<i>Search</i>	Search for Skype users
<i>Mute</i>	Mute microphone.
<i>ESC</i>	Equal to the key ESC

To enable the function keys to work, you must set the hotkeys for Skype according to the above

table. For detailed information of how to set the hotkeys, refer to **PhoneSkype SK-04 User Manual**

System Requirements

- Win98/ME/2000/XP/Linux
- USB port
- Pentium 300MHz above processor/128MB RAM/16MB free hard disk capacity
- Internet connection(ADSL, Cable Modem, Dial-UP, Wireless LAN)

Ordering Information

Model	Description
SK-04	Black or white color available